CTL 26 EI-FLR

Mobile Dust Extractor | CLEANTEC | Festool article 578152

A mains-powered L-class mobile dust extractor for professional floor layers. Washable wheel covers, shoe covers and an abrasion-resistant PUR cable help protect delicate flooring.

TECHNICAL SPECIFICATIONS

Dust classification	L
Power consumption	350–1,200 W
Maximum volume flow	3,900 l/min (turbine)
Maximum vacuum	24,000 Pa
Filter surface area	6,318 cm²
Container / filter bag	26 / 24 litres
Dimensions (L × W × H)	630 × 365 × 540 mm
Power cable length	7.5 m
Product weight (without accessories)	14.80 kg
Transport weight (including accessories)	17.10 kg
Drive type	Mains-powered
Maximum tool socket load	2,400 W (variant/market dependent)

CONTROL AND EXTRACTION FEATURES

Floor protection: Washable wheel covers, shoe covers and abrasion-resistant PUR cable help avoid marks on sensitive floors. **Manual filter cleaning:** Supports manual cleaning of the filter and filter bag. **Bluetooth:** Automatic activation with compatible Festool Bluetooth battery packs or an optional remote control. **Tool socket:** Automatic start/stop with compatible mains-powered tools. **Wet/dry:** Wet extraction is supported when prepared according to the operating instructions.

Applications & Equipment

MAIN APPLICATIONS

Dust extraction and cleaning during floor installation, interior finishing and maintenance on delicate surfaces; compatible tool dust collection and wet/dry cleaning. Dust class L applies to dust with occupational exposure limits greater than 1 mg/m³. Check material hazards and local requirements before use.

STANDARD SCOPE OF DELIVERY

Main filter	HF-CT 26/36/48
Filter bag	SELFCLEAN filter bag
Suction hose	D 27/32 × 3.5 m-AS/CTR
Wheel covers	RD-CT 26-48, washable
Shoe covers	SHOE-FT1

NOISE AND HANDLING

A-weighted sound pressure level	71 dB(A)
Noise uncertainty K	3 dB
Connectivity	Integrated Bluetooth; Festool app
Mobility	Wheeled chassis; hose storage; T-LOC compatibility

SAFETY AND CONFIGURATION NOTES

Use the extractor only for dust types permitted by its L-class classification. Do not use for hazardous dust requiring M- or H-class extraction. For wet extraction, prepare the machine and filters as instructed by Festool. Disconnect mains power before servicing, changing filters or emptying the container. Respect the appliance-socket load rating of the supplied regional variant.

SOURCE AND DOCUMENT STATUS

Prepared from the official Festool CTL 26 EI-FLR article 578152 product listing. Electrical socket ratings can vary by market. Confirm the supplied variant and its rating plate before publishing region-specific electrical specifications.

This is an independently prepared technical summary, not an official Festool-issued data sheet. Verify current specifications and safety requirements against Festool documentation.